

NOTICE TO NEW CUSTOMER

ATS SET UP PROCEDURES

Prior to use of this machine, please attach:

- 1-Hose hanger
- 2-Air fitting (not supplied)

Included in this machine are the following:

- HOSE HANGER
- NOTICE TO NEW CUSTOMER
- FORD ADAPTER FITTINGS
- CHRYSLER ADAPTER FITTINGS
- GM ADAPTER FITTINGS
- UNIVERSAL FITTINGS
- GEAR CLAMPS
- OPERATOR'S MANUAL

ATS Machine Priming Instructions:

Necessary steps when placing an ATS machine in a shop:

- 1) Pour new fluid in ATS machine
- 2) Hook up to 12 volt DC and turn power on.
- 3) Attach a universal open-end adapter to one of the black hoses and place it in the ATS fill neck.
- 4) On the keypad press "FILL 1.0" and press "START". Repeat this step two or three times.