

2016 Ford F-150 Hook Up

Fittings needed for the service.



Part# 601



Part# 600



Part# 7094



Part# DFM12

1. Attach **Part# 600** into the thermostat Block.



2. Attach Part# **601** to the line that came out from the thermostat block.



3. Now attach both open ends of **Part# 600** and **Part#601** to the Loop **Part# 7094**. This connection should look like the picture below. It does not matter which hose end you attach too **Part# 7094**. The other end of **Part# 7094** attaches to one of the hoses on the ATS machine.

Part# 7094 - This end attaches too one of the hoses off the ATS machine.

Part# 600 - This end is attached into the thermostat block on the vehicle.



Part# 601 - This end is attached to the line that came out of the thermostat block on the vehicle.

3. Attach **Part# DFM12** to dipstick plug on the right-hand side of vehicle transmission. Connect the other end of the **Part# DFM12** to one of the hoses off the ATS machine. All connections are now complete.

