

RCS 546/550/570 Fitting Kit #7091



Part# 7008

1 3/4" Straight Hose 6" Long



Part# 7009

1 1/2" Straight Hose 6" Long



Part # 7010

1 1/4" Straight Hose 6" Long



Part# 7011-1

2 - Gear Clamps 1 1/2 "
2 - Gear Clamps 2"



Part # 7012

1/2" and 3/8" Clear Hose
Adapter



Part # 7008-90

1 3/4" 90° Hose 4" Long



Part # 7009-90

1 1/2" 90° Hose 4" Long



Part # 7010-90

1 1/4" 90° Hose 4" Long



Part # 7008-2

2" Straight Hose 6" Hose



Part # 7009-2

2 1/2" Straight Hose 6"
Hose



Part # 7010-2

2 1/4" Straight Hose 6" Long



Part # 7013

5 Step Loop Hose



Part # 7014-1
3 Step Loop Hose for Diesel Trucks



Part # 7015
12" long 3/8" Clear Hoses and One Rubber Cone Adapter



Part# 7106
3/8" Hose Adapter



Part# 7106-1
1/2" Hose Adapter



Part# 7107
5/16" Hose Adapter



Part# 7107-1
BMW Return Hose Connection